


※ Precise parts are included. Please take care not to lose them.

Thank you for purchasing this Rokuhan product. Please read this instruction manual carefully before use.

### 1. Caution

- Install only on Rokuhan trains.
- Disassembling and modification could cause failure of this product.
- Store and use this product in dry dust free locations, away from sources of heat.
- This product includes sharp parts. Handle with care.
- Handle tools with care.
- This product is not recommended for use by children under 8 years old unless supervised by an adult.


### 2. Parts list



① CROSSING SLOPE . . . 4pcs  
 ② CROSSING CENTER W . . . 2pcs  
 ③ JOINT . . . . . 2pcs  
 ④ CROSSING STEP S . . . 2pcs  
 ⑤ CROSSING STEP L . . . 2pcs  
 ⑥ SIGNAL (L, R) . . . each 2pcs

### 3. How to assemble signal

⑥ SIGNAL (L & R) are assembled like this.




\* When any loose fit happens, please use any glue to fix.

### 4. How to set (Bottom view)

#### ● NARROW ROAD & DOUBLE TRACKS


Insert ③ into the center of ① and ②.



BOTTOM VIEW

#### ● WIDE ROAD & DOUBLE TRACKS

Insert ③ between 2 pcs each of ① and ②.




### 5. How to set (Upper view)

#### ● NARROW ROAD & DOUBLE TRACKS


Insert ③ into Power feed hole of the track and place ④ onto the track, then place ①, ② and ⑥ as figure 1 shows.

Figure 1



#### ● WIDE ROAD & DOUBLE TRACKS

In addition to above setting, replace ④ with ⑤, then increase one more of ①, ② and ⑥ respectively.



### 6. Trouble and repair

- The user is responsible for any trouble, accident, or injury caused by misuse, disassembly, reassembly or modification to this product. Rokuhan does not repair a product which has been opened, taken apart or modified.
- Specification and appearance of our products are subject to change without prior notification.
- Contact the following Rokuhan customer service if you have any query.